

Inseego Wavemaker™ FX3100 Indoor Router

Reference Guide



About Your FX3100

1. Dual TS9 External Antenna Ports
2. SIM slots (Nano 4FF Included in Slot 1)
3. DC power jack
4. Reset Button
5. 1 Gbps Ethernet WAN or LAN port
6. USB Type-C port