

Inseego MiFi® PRO M4 Reference Guide

Front



1. Power Button
2. SIM Access Tab
3. SIM Card Slot
4. Battery
5. (2) TS9 Antenna Ports
6. USB-C Port
7. RJ45 Ethernet Port

Back (cover removed)



Bottom



Top

